



NOTE:

1. SET MANHOLE, COMPLETE W/PIPE CONNECTIONS.
2. ELECTROFUSE FLEX RESTRAINTS
3. FORM AND POUR CONCRETE AROUND PIPE AND ENCASE FLEX RESTRAINT.