



DESIGN NOTE : THE NOTES BELOW ARE INTENDED FOR DAY LABOR CONSTRUCTED BIKEPATHS

CONSTRUCTION SEQUENCE

BY COUNTY:

1. GRADE BIKEWAY
2. INSTALL DRAINAGE AS NECESSARY
3. COMPACT SUBGRADE

BY CONTRACTOR:

4. REMOVE & REPLACE CURB & GUTTER AT STREET CROSSINGS
5. PLACE AGGREGATE AND COMPACT
6. PLACE TOPSOIL
7. PREPARE SEEDBED, FERTILIZE, SEED AND MULCH ALL DISTURBED AREAS

SCALE: 1" = 2'

REVISIONS	DATE
Revised Type A to Type B Aggregate	12/20/12
Revised to Limestone Screenings & 6" Depth	5/16/22



APPROVED BY: M. G. ZEMAITIS  
DATE: APRIL 1, 2007

**TYPICAL SECTION  
AGGREGATE BIKEPATH**

LC4050