



NOTE:

- ① UTILIZE FULL BODY SERVICE SADDLE FOR PVC AND DUCTILE IRON WATERMAIN (SMITH BLAIR #372)
- ② UTILIZE ELECTROFUSION SERVICE SADDLE FOR HDPE WATER MAIN (FRIATEC 'VA')
- ③ TRACER BOX AND TRACER WIRE REQUIRED ONLY IF SERVICE PIPE IS NOT COPPER
- ④ TRACER WIRE ACCESS BOX IN LAWN AREAS LIGHT DUTY BOX LD14; COPPERHEAD INDUSTRIES OR EQUAL.