



NOTES:

1. SET MANHOLE, COMPLETE WITH RUBBER BOOT PIPE CONNECTIONS.
2. ELECTROFUSE FLEX RESTRAINTS
3. FORM AND POUR CONCRETE AROUND PIPE AND ENCASE FLEX RESTRAINT.