



NOTES:

1. LCPW METER HAS TO BE INSTALLED ON A HORIZONTAL PIPE RUN.
2. CURB STOP SHALL BE LOCATED IN A HEATED SPACE.