



NOTE:

LCPW METER HAS TO BE INSTALLED ON A HORIZONTAL PIPE RUN.