


# ExpressVote Machine Setup

- 1) Place ExpressVote machine on table



- 2) Insert power pack brick into backside of ExpressVote machine



- 3) Plug power cord into power pack brick



- 4) Feed attached cord through the hole in the center of the table. Plug in cord to the nearest outlet.



5) Open side door with barrel key. This door is on the left side of the screen.



6) Turn on machine by pressing 'On' switch. Make sure machine is switched to 'Voter' for mode



7) Close and lock side door and insert privacy shield into table slots



8) \*\*\*Early Voting Machines will have double privacy shields. 2 machines can fit on the same table if needed. Adjust privacy shield and machines accordingly.

